

Vari*Lite VL1000(S) Fixture

[25][VL1000S]

Att'.	Steps	N/Dim	Max	Min	Profile	
1,	0,	0,	255,	0,	0	Intensity
3,	0,	0,	0,	255,	0	Pan Coarse
x3,	0,	0,	0,	255,	0	Pan Fine
4,	0,	0,	255,	0,	0	Tilt Coarse
x4,	0,	0,	255,	0,	0	Tilt Fine
6,	0,	0,	255,	0,	0	Focus
53,	0,	0,	255,	0,	0	Zoom
10,	0,	0,	255,	0,	0	Frost
11,	0,	0,	255,	0,	0	Cyan
13,	0,	0,	255,	0,	0	Yellow
12,	0,	0,	255,	0,	0	Magenta
8,	0,	0,	255,	0,	0	Gobo Selection
9,	0,	0,	0,	255,	0	Gobo Index/Rotation Coarse
x9,	0,	0,	0,	255,	0	Gobo Index/Rotation Fine
72,	0,	0,	255,	0,	0	Upper Shutter (Top Left Motor)
73,	0,	0,	255,	0,	0	Upper Shutter (Top Right Motor)
74,	0,	0,	255,	0,	0	Right Shutter (High Motor)
75,	0,	0,	255,	0,	0	Right Shutter (Low Motor)
76,	0,	0,	255,	0,	0	Lower Shutter (Bottom Right Motor)
77,	0,	0,	255,	0,	0	Lower Shutter (Bottom Left Motor)
78,	0,	0,	255,	0,	0	Left Shutter (Low Motor)
79,	0,	0,	255,	0,	0	Left Shutter (High Motor)
86,	0,	0,	0,	255,	0	Shutter Gate Rotate
17,	0,	0,	255,	0,	0	Silly Speed Control 1
18,	0,	0,	255,	0,	0	Silly Speed Control 2
19,	0,	0,	255,	0,	0	Silly Speed Control 3
20,	0,	0,	255,	0,	0	Reset